

Thermal and rheological characterization of PIB 1 and

PIB 2

Partners:

 University of Ljubljana, Faculty of Mechanical Engineering Laboratory for Numerical Modelling and Simulation Center for Experimental Mechanics Laboratory for Sustainable Technologies in Buildings
REFLEX Gornja Radgona d.o.o.
Slovenian National Building and Civil Engineering Institute University of Ljubljana, Faculty of Mathematics and Physics

No. of ARRS project: L2-3172

ARRS project title: Development of technical guidelines for quadruple glazing

Assoc. Prof. Miroslav Halilovič, PhD Project manager



Prof. Mihael Sekavčnik, PhD Dean of the l ME

Ljubljana, November 2021







ZΛG





Partners:	University of Ljubljana, Faculty of Mechanical Engineering (UL FME) Laboratory for Numerical Modelling and Simulation (LNMS)	
	Center for Experimental Mechanics (CEM)	
	Laboratory for Sustainable Technologies in Buildings (LOTZ)	
	Aškerčeva 6	
	SI-1000 Ljubljana	
	REFLEX Gornja Radgona d.o.o.	
	Podgrad 4	
	SI-9250 Gornja Radgona	
	Slovenian National Building and Civil Engineering Institute (ZAG) Dimičeva ulica 12	
	SI-1000 Ljubljana	
	University of Ljubljana, Faculty of Mathematics and Physics Jadranska ulica 19	
	SI-1000 Ljubljana	
Financial support:	The project is financialy supported from the Slovenian Research Agency ARRS (research project No. L2-3172) and the company Reflex d.o.o.	
No. of ARRS project:	L2-3172	
ARRS project title:	Development of technical guidelines for quadruple glazing	
Project manager:	Assoc. Prof. Miroslav Halilovič, PhD	
	Tel.: (01) 4771 439	
	E-mail: miroslav.halilovic@fs.uni-lj.si	
Report title:	Thermal and rheological characterization of PIB 1 and PIB 2	
Task manager:	Assist. Prof. Lidija Slemenik Perše	
Authors:	Urška Gradišar Centa. PhD	
	Alen Useli, PhD	
	Mohor Mihelčič, PhD	



LOTZ





Table of content

1.	S	SAMPLE PREPARATION	L
2.	. N	MEASUREMENT	<u>)</u>
	2.1	. DSC: phase transition temperatures	<u>)</u>
	2.2.	Rheology: determination of LTVE range @ 60°C	}
	2.3	Rheology: frequency sweep @ 60°C	ł
3.	. C	CONCLUSION	1





1. SAMPLE PREPARATION

Instrument:

Procedure details:

Modular rotational rheometer MCR302, Anton Paar

Sample geometry: Cylindrical disk (PP25/S sensor geometry): d=25 mm; h=1mm (gap)

System configuration: upper plate PP25/S (sandblasted); lower plate INSET/pp25/SS/S D:25 mm, SANDB; HETD 400

Figure 1 shows cylindrical disk sample (example of PIB 2), trimmed around PP25/S sensor geometry at 60°C.

Temperature: 60 °C

ZΛG



Figure 1: Trimmed cylindrical sample at 60°C.





2. MEASUREMENT

2.1. DSC: phase transition temperatures

Instruments:	DSC2500, Ta Instruments
Procedure details:	Temperature range: -80°C – 100°C
	Heating and cooling rate: 10°C/min
	Pan type: Al
	Sample geometry: finger kneaded granule
	Repetitions: 2 repetitions per material

Figure 2a and 2b show DSC thermograms of PIB 1 and PIB2, respectively, indicating glass transitions at - 65°C.



Figure 2: DSC thermograms of a) PIB 1 and b) PIB 2 (only 1. repetition is shown).





REFLEX

2.2. Rheology: determination of LTVE range @ 60°C

Instrument:	Modular rotational rheometer MCR302, Anton Paar
Procedure details:	Shear stress: 10 - 10000 Pa
	Temperature: 60°C
	Frequency: 1 Hz
	System configuration: upper plate PP25/S (sandblasted); lower plate INSET/pp25/SS/S D:25 mm, SANDB; HETD 400
	Gap: 1 mm
	Repetitions: 1 repetition per material

Figure 3 shows rheological amplitude sweep tests, which were performed in order to determine shear stress limit of linear viscoelastic range (LTVE) for PIB 1 and PIB 2, respectively. The results showed that for PIB the LVTE ended at 1000 MPa, while LVTE for PIB 2 was determined at 1650 MPa.



Figure 3: Determination of LVTE - storage G' and loss modulus G'' as a function of shear stress at 60°C.



2.3. Rheology: frequency sweep @ 60°C

Instruments:Modular rotational rheometer MCR302, Anton PaarProcedure details:Temperature: 60°CShear stress: 1000 Pa (within LTVE)Frequency: 0,01 - 100 HzSystem configuration: upper plate PP25/S (sandblasted); lower
plate INSET/pp25/SS/S D:25 mm, SANDB; HETD 400Gap: 1 mmRepetitions: 2 repetitions per material

ZΛG

Figure 4 shows viscoelastic behavior (storage G' and loss G'' modulus) of PIB 1 and 2 over a wide frequency range at constant temperature of 60°C (isothermal segment).



Figure 4: Storage G' and loss G'' modulus as a function of frequency at constant temperature of 60°C (average values are presented).

3. CONCLUSION

Differential dynamic calorimetry was used to determine the glass transition temperature which was for PIB 1 determined at -65 °C and -66.8 °C for PIB 2. At 60 °C, the storage modulus of PIB 1 dominated over the loss modulus up to the frequency of 0.1 Hz, where the flow point could be observed. At low frequencies, the storage modulus of PIB 1 decreased rapidly, indicating that the material at these conditions behaves as a liquid. On the other hand, the results for PIB 2 show that the storage modulus dominated the viscous one in the whole frequency range. For this sample, the flow point was not observed in the frequency range examined.